


A better way to install water and holding tanks.

This method allows for a more complete pump out for single or multiple holding tanks.

The HowFullAmI sender units may be installed at tank level or in the floor level manifold. When a manifold is used at the bottom of the tanks a single sender unit will monitor all connected tanks.

Connected to drain (pump out) and or a floor level multiple tank manifold.

Floor level



Water or holding tank

Non slip blocks should be placed around each tank .

3/4" Plywood

2X4 base